

Electro Optical Components, Inc.

5460 Skylane Boulevard, Santa Rosa, CA 95403 Toll Free: 855-EOC-6300





## **Offset Adjustment for Current Amplifiers**

Use the "Offset" screw adjustment on FEMTO current amplifiers when there is an output voltage with no input signal and this voltage is big enough to distort your output readings.

First, the amplifier should have a warmup time of at least 20 minutes before adjusting.

Adjust the offset screw on the amplifier until the output of the amplifier is near to zero or to a small enough value that is not distorting the output readings.