



Electro Optical Components, Inc.


5464 Skylane Boulevard, Suite D, Santa Rosa, CA 95403

Toll Free: 855-EOC-6300

www.eoc-inc.com | info@eoc-inc.com



Hyperspectral Imaging for PAT applications



inno-spec



is an established manufacturer of spectral imaging solutions for process analytical applications



Founded in 2005


inno-spec group
today: ~60 employees



Process Analytics



Process Analytical Technology (PAT) - a system for designing, analyzing and controlling critical quality and performance parameters of materials and manufacturing processes in real-time (i.e., during processing) with the goal to ensure the final product quality.



Process Analytics



Purpose

Scientific

- Process capability: understanding and control of manufacturing processes and sub-processes for predictive operations
- Reduce process variability
- Assuring product quality *during* production

Regulatory

- New products: possible regulatory discretion
- Existing products: Reduce risk of Out-Of-Spec product reaching customers

Business

- Improving speed and accuracy of decision making
 - Decrease scrap, rework, WIP, and returns
 - Increase yields, equipment utilization, improve energy and material usage
 - Increase market share, ROI, and stockholder value
-


Process Analytics



Task: going on-line

because laboratory analysis:

- Labor intensive
- Opportunities for errors occur
- Increased risk for product contamination
- Individual samples often are not representative enough
- Degradation of samples until these are analyzed
- High risk of out-of-spec production in between
- Automated processing is difficult due to the manual handling



HSI for Process Applications



Industrial Requirements


- Robustness
- Reliability
- Measurement speed (high frame rate)
- Optical performance (throughput, resolution, etc.)
- Price
- Support



Hyperspectral Imaging (HSI)



Image Acquisition Techniques





Hyperspectral Imaging (HSI)





Pushbroom Imaging System

Pushbroom (line scan imaging) device record a whole line of an image. A spectrum is generated for each point (spatial element - pixel) on the line.



HSI Technology




Product Overview



190 - 380nm
(Forensics)

UV
Ultra
Violet



750 - 1100nm
(Food / Agriculture)

VNIR
Very Near
Infrared



2000 - 5000nm
(Mining)

MIR
Mid
Infrared



VIS
Visible

360 -780nm
(Color / Fluorescence)

400 - 1000nm
(Remote Sensing)

NIR
Near
Infrared

920 - 1700 / 2200nm
(Recycling / Food)

LWIR
Long Wave
Infrared




Hyperspectral Imaging

From UV to MIR



190 - 380nm
(Forensics)

UV
Ultra
Violet



750 - 1100nm
(Food / Agriculture)

VNIR
Very Near
Infrared



2000 - 5000nm
(Mining)

MIR
Mid
Infrared



VIS
Visible



NIR
Near
Infrared



LWIR
Long Wave
Infrared

360 - 780nm
(Color / Fluorescence)

950 - 1700 / 2200nm
(Recycling / Food)


400 - 1000nm
(Remote Sensing)



BlueEye UV Spectral Imaging System



- Wavelength range 190nm - 380nm
- Reflection spectrograph
- 1024 x 1024px back-illuminated CCD detector
- USB 2.0 interface



GreenEye Imaging System



- Transmission spectrograph
- Wavelength range 400 nm - 1000 nm
- CMOS Camera
- 54 Hz at full resolution
- Gigabit Ethernet
- Made for operation in harsh environments
- SDK



OrangeEye Scan Laboratory Spectral Imaging System



- Wavelength range 500nm - 950nm
- Pushbroom imager with integrated scanning unit
- Integrated broadband LED illumination
- No movement of samples or camera necessary
- USB 3 data interface



OrangeEye

Imaging transmission spectrograph




- Wavelength range 580nm - 1000nm
- CMOS Camera
- 108 Hz at full resolution
- Gigabit Ethernet
- Made for operation in harsh environments
- SDK






- High-class imaging transmission spectrograph & InGaAs NIR camera
- Frame rates up to 330 Hz at full resolution
- Spectral ranges 950nm – 1700nm & 1200nm – 2200nm




- Made for operation in harsh environments
- Gigabit Ethernet interface
- Customization
- SDK available



Color & NIR combined system



- Material and color determined at the same time
- Dichroic beam splitter
- 5 MPx RGB camera
- Spectral imaging system RedEye 1.7




BlackEye Imaging reflection spectrograph



- Wavelength range 2900nm – 4200nm
- InSb Camera
- 383 Hz at full resolution
- Gigabit Ethernet/ CameraLink
- Made for operation in harsh environments
- SDK





Staring imaging system




The same area is recorded at different wavelengths


The wavelengths are separated by tunable filters or filter wheels




red



green




blue



Accessories: Conveyor belt





- Use of high-quality materials like stainless steel and aluminum
- Large selection of transport belts
- Internal drive which means no disturbing contours
- Simple installation
- Low power consumption with high transport capacity
- Customized solutions are available on request



Accessories: Multi-fiber systems





By adding a multi-fiber bundle instead of the fore optics a pushbroom imaging system can be used as a multi-point spectrometer.



Accessories: LED line lighting



- Standard configuration with RGB LEDs, other LED wavelengths available on request
- Single and multichannel trigger operation
- Pulse width from $2\mu\text{s}$ – 65ms
- Trigger frequency up to 80kHz
- Available in variable lengths





Software



SiCap GB (inno-spec)

Data acquisition Software

- Spectral camera parameterization
- Data handling
- Translation control for inno-spec stepper table




Software



Breeze (Prediktera)

- Software for multivariate image and data analysis
- Complete solution with efficient touch screen user interface
- User-friendly, fast and easy to use



Prediktera.



Software



Perception System (Perception Park)

- chemical color imaging
- data processing solution enabling industrial hyperspectral imaging
- including hardware perception box



Software



Perception Studio (Perception Park)

- chemical color imaging
- interpretation of hyperspectral data without in depth knowledge of the statistical methods
- software is suited for hyperspectral data acquisition and processing





Software



HSP Food Analyzer (BT-A)

- chemical color imaging
- software package for hyperspectral data processing
- specialized for food





Application example

Wood processing sector



- Improved sorting of scrap wood
- Monitoring of moisture and adhesive distribution on wood-based material surfaces
- Quality assurance in the production of wood-based boards
- RedEye 2.2: 1200nm – 2200nm (extended InGaAs)




Application example

Pill packaging



- Measurements through not transparent packaging in the 950 nm – 1700 nm spectral range
- Identification of different pill categories in the blister
- Detection of missing or false pills








Application example

Ibuprofen tablet



Ibuprofen distribution measurements in the tablets: adult vs. child dosage





Prediktera.

Application example

Tree trunk analysis




Identification of different trunk zones




Application example


Paper moisture measurements




Normalised pseudo absorbance spectrum



Max variance image




Variance scatter



Quantitative moisture profile mapping on paper rolls performed using RedEye HSI system in the 950 nm - 1700 nm spectral range.

Application example

Identification of potatoes, stones and soil



- Soil and stones must be removed before further processing of the potatoes but they can often not be discriminated by color
- VNIR 750 nm – 1100 nm spectral imaging identification performed with high certainty




Application example

Almond processing



Detection of almond shells and other foreign objects in the processing line.






Application example

Flakesorter



Sorting of plastics or minerals

- Colour sorting for grain size fraction 1-40 mm
- NIR sorting for grain size fraction 5-40 mm
- Sorting width: 750 mm
- Belt speed: 3 - 4,5 m/s
- Line rate for colour sorting >10 kHz (> 2000 px/ line)
- Frame-Rate for NIR sorting up to 330 Hz (with reduced spectral resolution also > 1kHz)



Customized Solutions

Blood analysis



- Non invasive blood analysis in the spectral range of 500-850 nm
- Measuring under the skin surface
 - tissue penetration depth of several mm
- Special development
- Cost efficient miniaturization of optics and electronics
- max. size 50x15x15 mm

